

# ***PRIntX40I/V User Manual***



---

**Synel Industries Ltd.**

PRintX40I/V 30/8/04 Part no.650401 (PRintX40-222-02)

This document has been prepared for PRintX40I/V device. All rights reserved. Reproduction or use, without express permission of editorial or pictorial content, in any manner is prohibited. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this manual, Synel Industries Ltd. assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein. DCM and SY are trademarks of Synel Industries Ltd. All trade names referenced herein are either trademarks or registered trademarks of their respective companies.

**Table of contents**

1. Introduction .....1

1.1 Differences between PRIntX40I & PRIntX40V .....1

1.2 Technical Specifications.....1

1.3 Man-machine Interface.....2

1.4 Mechanical Features .....2

1.5 Package.....2

2. Installation .....3

2.1 Wires Connection .....5

3. Operation .....8

3.1 Access Control using PRIntX40I/V unit .....8

3.2 Programming Mode.....9

4. Maintenance .....16

# 1. Introduction

PPrintX40I/V is a biometric stand-alone controller, one of the series of Synel's access control protocols. It is a unit that operates with either a fingerprint verification version - PPrintX40V (catalogue number 00430) or a fingerprint identification version - PPrintX40I (catalogue number 00431) further to user-card reading (by the proximity unit). The proximity and biometric units are adjacently installed at sensitive locations for granting access to secure areas. The PPrintX40I/V works with various unit settings, according to the security level required at the location of the unit. Defining parameters is simple while maximum security is enabled by using a password defined by the user. Access is available for upto 4000 card holders in the verification version, and upto 200 card holders in the identification version, stored in an authorized list. This list is created and edited using keyboard.

## 1.1 Differences between PPrintX40I & PPrintX40V

- (PPrintX40I) Identification does not require a card/code. Upto 200 fingerprint templates are stored in the terminal's memory. Whenever an employee places his finger on the sensor, the FP (fingerprint) unit polls all existing templates until there is a match and confirms/rejects.
- (PPrintX40V) Verification requires a card/code. The template is stored in reference to a card/code. Upto 4000 card/codes and templates are stored. When an employee swipes his card/keys-in his code, the unit checks if the card/code number exists, if it does it checks also the template assigned to that number.

## 1.2 Technical Specifications

- Maximum Range: 10 cm (4 inches)
- Operating Frequency: 125 kHz
- RS-232 or RS-485 (ASCII); 9600 b/s
- Storage for 4000/200 templates
- Sensor vendor: Bioscript
- False rejection rate:0.001
- False acceptance rate:0.001

## 1.3 Man-machine Interface

- Indicator for: Power, card confirmation/rejection and keyboard entry, fingerprint (a tri-color led)
- 10-digit keyboard
- Bell button
- RF coupling of proximity card
- Buzzer for audio confirmation of operations

## 1.4 Mechanical Features

- Dimensions: 137X115X28 mm
- Weight: 360gr
- Operating temperature: 0 to +60°C
- PPrintX-40I\_V Power supply: 12Vdc, 20.5A
- PPrintX Power supply: 5Vdc 21A
- Output relay rating: 24 V @ 3 A
- Tamper sensor output TTL level max @ 16 mA

## 1.5 Package

- PPrintX-40I\_V proximity reader
- PPrintX/P biometric reader verification/identification
- PPrintX/P power supply adaptor: 5 Volt/1 A stabilized wide range input 100-240 AC input
- RJ-11 Connection box with 5V power input
- RJ-45 Connection box
- Four 3.5x50mm Philips screws, four 3.5x19mm Philips screws and four for position B, four Brick/Plaster anchors
- Mounting template
- User manual

Recommended: PPrintX-40I\_V Power supply adaptor: 12 to 15 Vdc, max @ 880 mA

## 2. Installation

The PPrintX40I/V readers are installed in any type of facility. The following guidelines are to be used when installing the units:

- Keep the cable assembly separated from and at least 30 cm away from any cable.
- Use a power adaptor dedicated to the proximity unit. Make sure the adapter carries a safety recognition marking such as UL, CSA or CE.

*Note: When using the identification feature the finger unit can be installed outside the door and the PRX40 reader installed in the inner side of the door (designated for setup only!).*

While following step by step instructions for mounting, refer to the diagram below and the mounting template (CAT No. 600090, MD600090-01-A):



1. Disassemble PReintX-40I\_V and RJ-45 connection box wiring, in order to route cable.
2. Two mounting options are available for this unit:
  - Option A- Mounting the assembled unit to the wall, using four screws threaded through holes at the top and bottom of the unit (1)
  - Option B - Mounting the disassembled back panel to the wall, after concluding this procedure re-assemble unit's front panel and secure screws.

**Option A:**

- Step 1. Remove screw covers and screws from top and bottom of the units front panel (1).
- Step 2. Drill holes according to position A shown on the mounting template, for both units PReintX-40I\_V and PReintX.
- Step 3. Route PReintX-40I\_V wiring.
- Step 4. Place two screws in position A, one at the top position and one at the bottom position; secure PReintX-40I\_V to the wall.
- Step 5. Route PReintX wiring.
- Step 6. Slide groove on the PReintX against PReintX-40I\_V slip.
- Step 7. Place two screws in position A, one at the top position and one at the bottom position; secure PReintX to the wall.
- Step 8. Proceed according to wires connection instructions, page -5.

**Option B:**

- Step 1. Remove screw covers and screws from top and bottom of the unit front panel (1).
- Step 2. Remove back panel.
- Step 3. Drill holes according to position B shown on the mounting template, for both units PReintX-40I\_V and PReintX.
- Step 4. Fasten back panel on the wall (2), place two short screws in position B. Secure PReintX-40I\_V to the wall.
- Step 5. Route the cable wires via centre hole C.
- Step 6. Route PReintX-40I\_V+PReintX wiring.
- Step 7. Slide groove on the PReintX against PReintX-40I\_V slip.
- Step 8. Fasten back panel on the wall (2), place two short screws in position B. Secure PReintX to the wall.
- Step 9. Route the cable wires via centre hole C.
- Step 10. Place and secure PReintX-40I\_V+PReintX front cover (2) using two

short screws (position A).

Step 11. Proceed according to wires connection instructions, page -5.

## 2.1 Wires Connection

There are three connection types:

### 2.1.1 PPrintX-40I\_V Power supply, door lock & bell connection

The PPrintX-40I\_V (PRX40 unit) 12 wiring connection used for the door relay, bell and power supply control; for color codes refer to the table below.

Wire No.	Wire Function	Present Color Code
1	Vin Power (VCC)	Red
2	Gnd	Black
3	- TxRx RS-485	Grey
4	+ TxRx RS-485	Purple
5	TxD RS -232	White
6	RxD RS -232	Green
7	Tamper Control	Brown
8	Normal Neutral (C)	Blue
9	Normal Close (N.C.)	Yellow
10	Normal Open (N.O.)	Orange
11	Bell (1)	Black/White
12	Bell (2)	Red/White

### 2.1.2 PPrintX-40I\_V and PPrintX/P connection

Wiring instructions:

1. Insert the PRX40's RJ-45 connection box at its hidden position on the wall.
2. Connect PPrintX/P unit's flat RJ-45 connector to connection box.




**PRintX - RJ-45 Connection Box (reference)**

Wire function	PRintX - P2 (5 Pin female)	PRintX - P3 (7 Pin female)	Wire No.	Connection box Colour Code
GND		5	1	BL
Wiegand data 1		2	2	OR
Wiegand data 0		1	3	BK
Led1	1		4	RD
Led2	3		5	GR
Not used			6	YL

3. Connect PRintX-40I\_V to RJ-45 connection box, route 5 wires as follows:

**PRX40 (J1) - RJ-45 Connection Box**

PRX40 Wire Function	Cable Col- our Code	Wire No.	Connection box Colour Code
GND	Black	2	OR
Wiegand data 0	Green	4	RD
Wiegand data 1	White	3	BK
LED 1	Yellow	6	YL
LED 3	Blue	7	BR



**2.1.3 PRintX/P - HOST Connection**

This connection provides a communication interface and power supply to PRintX/P, whenever a host connection is required (MV1000):

*Note: Commonly, this unit is unplugged from host. It is mainly plugged-in for FPU maintenance purposes.*

- 1. Place RJ-11 connection box in its hidden position on the wall.
- 2. Connect PRintX/P flat RJ-11 connector to connection box.
- 3. Connect DC-Input jack to RJ-11 connection box.

**PRintX - RJ-11 Connection box (reference)**

Wire No.	Wire Function	Present Colour Code
1	TXD	Blue
2	GND	Yellow
3	RXD	Green
4	NC	-
5	NC	-

6	VCC	White
---	-----	-------

## 3. Operation

### 3.1 Access Control using PPrintX40I/V unit

1. Bring user-card within range of PPrintX-40I\_V (Verification only).
2. Place user-finger on the PPrintX sensor.
3. Compatibility between card-user and finger-user enables access - activates door relay.
4. No compatibility between user-card and user-finger prevents access and initiates a buzzer sound - door relay was not activated.

The PPrintX/P reader allows for two basic operations:

**Enrolment** - is scanning a fingerprint, determining the quality of the fingerprint scan and storing a good template as a reference (See “Managing Access Cards or Codes” on page -13).

**Verification** - is proofing of the currently scanned fingerprint against the stored fingerprint templates for that user. PPrintX operates as a server, interacts to accept PPrintX-40I\_V instructions. A four-mode led is designated for status indication:.

<b>Flashing orange</b>	A flashing orange led indicates that the employee is requested to place his finger for sampling purposes, while Enrolment process is on.
<b>Orange</b>	Waiting for fingerprint validation, while performing verification.
<b>Green</b>	Successful operation.
<b>Red</b>	Failure.

A led is activated to indicate current status, when operation is completed the results are transmitted to PPrintX-40I\_V.

## 3.2 Programming Mode

The PPrintX-40I\_V divides its tasks into three categories:

1. Management of System Tools
2. Management of Access Cards (authorized personnel)
3. Management of System Tasks

### **How to Enter programming mode?**

All system management requires entering the system.

1. Press 3 times simultaneously on function-keys 1&2 (each time will be followed by a short beep and an orange LED will be lit).
2. Key-in the eight digit Master-Card code (default – 12345678).  
It is recommended that the client change this code later.
3. After entering “Programming Mode” you can define parameters, as follows:

*Note: This is a continuous procedure a delay while entering parameters will promote the Programming mode after a short time-out*

All definitions of Management modes are listed in the table below.

<b>Function Description &amp; Glossary Number</b>	<b>Code</b>	<b>Value</b>	<b>Default</b>	<b>Remarks</b>
<b>Management of System Tools</b>				
Initialisation of Memory	06	9210		
Operation Mode	12	0006	0000	<b>Card and FP</b>
Operation Mode	12	0008	0000	<b>Code and FP or FP only</b>
<b>Management of Access Cards (Authorized Personnel)</b>				
Insert card(s) to PRX - 40 list and Fingerprint	20	9999		*
Delete cards from list for PRX - 40 and fingerprint	21	8888		**
<b>Management of System Tasks</b>				
Open Door Time	10	0000-0225	1	0 To 25.5 Seconds
Open Door	00	0000		Opens the relay for <i>Door Open Time</i>
Set New Master Code	13	xxxxx xxxx	123456 78	Must consist of 8 digits

\* Operation mode - card and FP

Bring Card within PPrintX-40I\_V range. Place your finger on the PPrintX unit, you have 10 sec. to acknowledge; Press:

To insert -1

To exit - 2

Operation mode - code and FP

Key-in a 4 digit code. Place your finger on the PPrintX unit, you have 10 sec. to acknowledge; Press:

To insert -1

To exit - 2

\*\* Operation mode - card and FP

Bring Card within PPrintX-40I\_V range. You have 10 Sec to acknowledge; Press:

To delete -1

To exit - 2

Operation mode - code and FP

Key-in a 4 digit code. You have 10 sec. to acknowledge; Press:

To delete -1

To exit - 2

### 3.2.1 Management of System Tools

#### Set New Master Code

The Master Code can be changed using the “Instruction Code” – 13. After entering “Programming Mode” key-in “13” followed by an eight digit number that will serve as a New Master Code. It is recommended to change the Master Code default immediately after installing the unit.

#### Memory Initialisation

**Warning:** *All data saved on PPrintX-40I\_V will be deleted.*

This options deletes all cards in the memory. “Initialisation of Memory” takes a few seconds to complete - (the green LED blinks) wait until you hear the buzz, signifying completion.

### **Operation Mode**

#### **Card and Finger Print (verification only)**

Control is performed by Card and card holder fingerprint accepted by the PReintX unit:

1. Press 3 times function-keys 1&2 simultaneously. The red LED flashes.
2. Key-in the eight digit Master-Card code (default – 1234...8).
3. Key-in Instruction code 12 and “0006”.

#### **Code and FP (only in PReintX40I\_V - FP)**

Control is performed by code and fingerprint accepted by the PReintX unit. If the fingerprint unit is in auto-detection mode (identification) the user does not need to Key-in the code, just place his finger on the sensor:

1. Press 3 times function-keys 1&2 simultaneously. The red LED flashes.
2. Key-in the eight digit Master-Card code (default – 1234...8).
3. Key-in the instruction code 12 and “0008”.

### **3.2.2 Managing Access Cards or Codes**

#### **Insert Cards Into List**

- Cards may be entered one at a time or one directly followed by another. When the green LED flashes, the PReintX-40I\_V is ready to read cards, the card (s) must be brought within the unit's range.
- Upon completion of card insertion, the operation is cancelled and reverted to Programming mode after a short time-out (is if operation is not acknowledged within 10 sec.).

Inserting cards can be performed following this procedure:

1. Press function-keys 1&2 3 times simultaneously. The red LED flashes.
2. Key-in the eight digit master code. You are Programming mode.
3. Key-in the instruction code 20 and “9999”.
4. PReintX orange LED flashes.
5. Bring user-card within the range of the PReintX-40I\_V; The PReintX's orange LED is illuminated.
6. Place user-finger on PReintX sensor; green LED indicates success.
7. You have 10 Sec to acknowledge:
  - For card insertion press (1)
  - For exiting press (2).



### **Insert Codes Into List**

- Codes may be keyed-in one at a time or one directly following another. When the green LED flashes, the PPrintX-40I\_V is ready to read cards, the card(s) must be brought within range of the unit.
- Upon completion of code insertion, the operation is cancelled and promoted back to Programming mode.

Inserting codes can be performed following this procedure:

1. Press 3 times function-keys 1&2 simultaneously. The red LED flashes.
2. Key-in the eight digit master code. You are in Programming mode.
3. Key-in code 20 and “9999”.
4. PPrintX orange LED flashes.
5. Key-in the four digit user code; PPrintX orange LED is illuminated.
6. User-finger should be no placed on PPrintX sensor; green LED indicates success.
7. You have 10 sec. to acknowledge:
  - To insert an additional card (1).
  - To exit this mode press (2).

*Note: In auto-detection mode there is a limit of upto 200 fingerprint template.*

### **Delete Card(s) from List**

Deleting cards can be performed following this procedure:

- Cards may be deleted one at a time or one directly following another. When the green LED flashes, the PPrintX-40I\_V is ready to read cards, the card(s) must be brought within range of the unit.
  - This operation is cancelled and reverted to programming mode after a short time-out (if the operation is not acknowledged within 10 sec).
1. Press function-keys 1&2 3 times simultaneously. The red LED flashes.
  2. Key-in the eight digit Master-code (default – 1234...8). You have entered programming mode.
  3. Key-in code 21, key-in the four digit Master-Card code (8888).
  4. PPrintX red LED flashes.
  5. Bring User-card within range of PPrintX-40I\_V.
  6. You have 10 sec. to acknowledge:
    - To delete an additional card press (1).
    - To exit press (2).

### **Delete Code(s) from List**

Deleting cards can be performed following this procedure:

- Codes may be deleted one at a time or one directly following another. When the green LED flashes, the PRintX-40I\_V is ready to read codes, the card(s) must be brought within the unit range.
- This operation is cancelled reverted to programming mode after a short time-out (if operation is not acknowledged within 10 sec).
  1. Press function-keys 1&2 3 times simultaneously. The red LED flashes.
  2. Key-in the eight digit Master-code (default – 1234...8). You are in programming mode.
  3. Key-in code 21, key-in the four digit Master-code (8888).
  4. PRintX red LED flashes.
  5. Key-in user code.
  6. You have 10 sec. to acknowledge:
    - To delete an additional code (1).
    - For exit mode press (2).

## **3.2.3 Management of System Tasks**

### **Open Door**

Access can be given by using a Master Code. After keying-in “Programming Mode,” key-in “0” six times.

### **Open Door Time**

It is possible to adjust the “window” of accessibility during which a door opens when accessed. For example, if only one person enters, you may decide that 1.5 seconds is enough time for the user to open the door - but if more than one is expected to enter, you can choose to prolong door opening time. Thus, after entering “Programming Mode,” key-in the number “10” and then four digits. For example if you key-in 0015, the delay time will be 1.5 seconds.

## **3.2.4 FPU operation - Instructions and regulations:**

1. Do not use your thumb to enroll.
2. Place the higher joint of your finger on the ridge lock and lower your finger onto the sensor surface (make sure all other fingers are held straight to avoid creating an angle between the enrolled finger and the sensor surface - incorrect positioning).

3. Touch the sensor's plastic casing (black) in order to discharge static electricity. Keep your finger steady!
4. Press your finger gently onto the panel, avoid excessive pressure as it will blur the print.
5. Make sure your finger is touching the sensor's drive ring.
6. Use the **same** finger for enrollment as well as for verification.
7. If your finger is extremely dry, touch your forehead or the side of your nose before placing it on the sensor.
8. Do not use a wet/moist finger for scanning.

*Note: For user's convenience mount the terminal to a 1.3 meter height (measured from the top end of the terminal) and at a distance of 15 cm from the right-side wall (closer to the sensor side).*

## 4. Maintenance

You should always touch the conductive plastic before touching the PPrintX/P sensor in order to safely discharge any static electricity on your skin or clothing.

Do not:

- Place the fingerprint sensor close to a heating source, such as a radiator or hot plate
- Spill any liquids on the sensor with the exception of isopropyl alcohol.
- Subject the fingerprint sensor to heavy shocks or vibrations.
- Allow the sensor to come in contact with metallic objects.



---

Main Branch: Synel Industries Ltd. Yokneam Industrial Park, 2 Hamada St.,  
POB 142, Yokneam 20692, Israel  
Tel: +972-4-959 6777 Fax: +972-4-959 0729 E-mail: [info@synel.com](mailto:info@synel.com),  
Site: [www.synel-ind.com](http://www.synel-ind.com)  
Tel-Aviv Branch: Synel Systems Ltd. Tel: +972 9 775 0400  
UK Branch: Synel Industries (UK) Ltd. Tel: +44-181-900 9991  
North America Branch: Synel Systems N.A. Tel: +1-905-678 2605